Energy Management Multifunction indicator Type WM12-96





- Accuracy ±0.5 F.S. (current/voltage)
- Multifunction indicator
- Display of instantaneous variables: 3x3 digit
- Variable system and phase measurements: W, W_{dmd}, var, VA, VA_{dmd}, PF, V, A, An, Hz
- A_{max}, W_{dmd max} indication
- TRMS meas. of distorted sine waves (voltages/currents)
- Power supply: 24V, 48V, 115V, 230V, 50-60Hz; 18 to 60VDC
- Protection degree (front): IP65
- Front dimensions: 96x96mm
- Optional RS422/485 serial output
- Alarms (visual only) V_{LN}, An

Product Description

3-phase multifunction power indicator with built-in programming key-pad. Particularly recommended for displaying the main electrical variables.

Housing for panel mounting, (front) protection degree IP65 as standard, and optional RS485 serial output.

How to order WM12-96 AV5 3 D X Model Range code System Power supply Option

Type Selection

Range codes	System	Pov	ver supply	Opti	ons
AV5: 380/660V _{L-1} /5(6)AAC VL-N: 185 V to 460 V VL-L: 320 V to 800 V AV6: 120/208V _{L-1} /5(6)AAC VL-N: 45 V to 145 V VL-L: 78 V to 250 V Phase current: 0.03A to 6A Neutral current: 0.09 to 6A	3: 1-2-3-pha unbalanc with or w neutral	d load,	24VAC -15+10%, 50-60Hz 48VAC -15+10%, 50-60Hz 115VAC -15+10%, 50-60Hz 230VAC -15+10%, 50-60Hz 18 to 60VDC	X: S:	None RS485 output

Input specifications

Rated inputs Current	3 (shunt)	Sampling rate	1400 samples/s @ 50Hz 1700 samples/s @ 60Hz
Voltage	4	Display refresh time	700ms
Accuracy (display, RS485)	with CT=1 and VT=1 AV5:	Display	
(@25°C ±5°C, R.H. ≤60%)	1150W-VA-var, FS:230VLN, 400VLL; AV6: 285W-VA-var, FS:57VLN, 100VLL	Type Read-out for the instant. var.	LED, 14mm 3x3 DGT
Current	0.25 to 6A: ±(0.5% FS +1DGT) 0.03A to 0.25A: ±7DGT	Measurements	Current, voltage, power, power factor, frequency TRMS measurement of
Neutral current	0.25 to 6A: ±(1.5% FS +1DGT) 0.09A to 0.25A: ±7DGT	Coupling type	distorted waves. Direct
Phase-phase voltage	±(1.5% FS +1 DGT)	Crest factor	< 3, max 10A peak
Phase-neutral voltage	±(0.5% FS + 1 DGT)	Input impedance	
Active and Apparent power, Power factor	0.25 to 6A: ±(1% FS +1DGT); 0.03A to 0.25A: ±(1% FS +5DGT)	380/660V _{L-L} (AV5) 120/208V _{L-L} (AV6) Current	1 MΩ ±5% 453 KΩ ±5% ≤ 0.02Ω
Reactive power	eactive power 0.25 to 6A: ±(2% FS +1DGT);		48 to 62 Hz
_	0.03A to 0.25A: ±(2% FS +5DGT)	Overload protection Continuous voltage/current	1.2 F.S.
Frequency	±0.1%Hz (48 to 62Hz)	For 500ms: voltage/current	2 Un/36A
Additional errors			
Humidity	≤0.3% FS, 60% to 90% RH		
Temperature drift	≤ 200ppm/°C		



RS485 Serial Output Specifications

RS422/RS485 (on request)

Type

Connections

Addresses

Protocol

Multidrop bidirectional (static and dynamic variables) 2 or 4 wires, max. distance

1200m, termination directly

on the instrument

1 to 255, key-pad selectable MODBUS/JBUS

Data (bidirectional)

Dynamic (reading only) Static (writing only)

Data format

Baud-rate

System and phase variables All configuration parameters 1 bit di start, 8 data bit, no parity, 1 stop bit 9600 bit/s

Software functions

Password 1st level 2nd level	Numeric code of max. 3 digits; 2 protection levels of the programming data Password "0", no protection Password from 1 to 999, all data are protected	Displaying 3-phase system with neutral	Up to 3 variables per page Page 1: V L1, V L2, V L3 Page 2: V L12, V L23, V L31 Page 3: AL1, AL2, AL3 Page 4: An Page 5: W L1, W L2, W L3 Page 6: PF L1, PF L2,
System selection	3-phase with neutral 3-phase without neutral 3-phase ARON 2-phase Single phase		PF L3 Page 7: var L1, var L2, var L3 Page 8: VA L1, VA L2, VA L3 Page 9: VA ∑, W ∑, var ∑ Page 10: VA dmd, W dmd, H7
Transformer ratio CT VT	1 to 999 1.0 to 99.9		Page 11: Wdmd MAX Page 12: VL-L ∑, PF ∑ Page 13: A MAX
Filter Operating range Filtering coefficient Filter action	0 to 99.9% of the input electrical scale 1 to 16 Measurements, alarms, serial output	Alarms	Programmable, for the VL∑ and An (neutral current). Note: the alarm is only visual, by means of LED on the front of the instrument.
	(fundamental variables: V, A, W and their derived ones).	Reset	Independent alarm (VL∑, An) max: A, Wdmd

Power Supply Specifications

Auxiliary power supply 230VAC

-15 +10%, 50-60Hz 115VAC -15 +10%, 50-60Hz 48VAC

-15 +10%, 50-60Hz

Power consumption

24VAC -15 +10%, 50-60Hz 18 to 60VDC AC: 4.5 VA DC: 4W

General Specifications


Operating temperature Storage temperature	-5 to +50°C (23 to 122°F) (RH < 90% non condensing at 40°C) -30 to +60°C (-22 to 140°F) (RH < 90% non condensing at	RS485.	500VAC/DC between measuring inputs and 4000VAC, 500VDC between power supply and RS485
	40°C)	Dielectric strength	4000 VAC (for 1 min)
Installation category	Cat. III (IEC 60664, EN60664)	EMC	
Insulation (for 1 minute)	4000VAC, 500VDC between measuring inputs and power supply.	Emissions	EN50084-1 (class A) residential environment,



General Specifications (cont.)

Immunity	commerce and light industry EN61000-6-2 (class A) industrial environment.	Dimensions (WxHxD) Material	96 x 96 x 63 mm ABS self-extinguishing: UL 94 V-0
Pulse voltage (1.2/50µs)	EN61000-4-5	Mounting	Panel
Safety standards	IEC60664, EN60664	Protection degree	Front: IP65 (standard),
Approvals	CE, cULus		NEMA4x, NEMA12 Connections: IP20
Connections 5(6) A Max cable cross sect. area	Screw-type 2.5 mm ²	Weight	Approx. 400 g (pack. incl.)
Housing			

Waveform of the signals that can be measured



 $\begin{tabular}{lll} Figure A & Sine wave, undistorted \\ Fundamental content & 100\% \\ Harmonic content & 0\% \\ A_{rms} = & 1.1107 \ | \ \overline{A} \ | \ \hline \end{tabular}$




Figure B
Sine wave, indented
Fundamental content 10...100%
Harmonic content 0...90%
Frequency spectrum: 3rd to 16th harmonic
Additional error: <1% FS




Figure C
Sine wave, distorted
Fundamental content 70...90%
Harmonic content 10...30%
Frequency spectrum: 3rd to 16th harmonic Additional error: <0.5% FS

Display pages

Display variables in 3-phase systems (in a 3-phase system with neutral)

No	1st variable	2 nd variable	3 rd variable	Note
1	V L1	V L2	V L3	
2	V L12	V L23	V L31	Decimal point blinking on the right of the display
3	A L1	A L2	A L3	
4	An	AL.n		AL.n if neutral current alarm is active
5	W L1	W L2	W L3	Decimal point blinking on the right of the display if generated power
6	PF L1	PF L2	PF L3	
7	VAR L1	VAR L2	VAR L3	Decimal point blinking on the right of the display if generated power
8	VA L1	VA L2	VA L3	
9	VA system	W system	VAR system	
10	VA dmd (system)	W dmd (system)	Hz (system)	dmd = demand (integration time selectable from 1 to 30 minutes)
11		W dmd MAX		Maximum sys power demand
12	V LL system	AL.U	PF system	AL.U= is activated only if one of VLN is not within the set limits
13	A MAX			max. current among the three phases



Used calculation formulas

Phase variables

Instantaneous effective voltage

$$V_{1N} = \sqrt{\frac{1}{n} \cdot \sum_{i=1}^{n} (V_{1N})_{i}^{2}}$$

Instantaneous active power

$$W_1 = \frac{1}{n} \cdot \sum_{i=1}^{n} (V_{1N})_i \cdot (A_1)_i$$

Instantaneous power factor

$$\cos \varphi_1 = \frac{W_1}{VA_1}$$

Instantaneous effective current

$$A_1 = \sqrt{\frac{1}{n} \cdot \sum_{i=1}^{n} (A_1)_i^2}$$

F1= 315mA

Instantaneous apparent power

$$VA_1 = V_{1N} \cdot A_1$$

Instantaneous reactive power

$$VAr_1 = \sqrt{(VA_1)^2 - (W_1)^2}$$

System variables

Equivalent 3-phase voltage

$$V_{\Sigma} = \frac{V_1 + V_2 + V_3}{3} * \sqrt{3}$$

3-phase reactive power

$$VAr_{\Sigma} = (VAr_1 + VAr_2 + VAr_3)$$

3-phase active power

$$W_{\Sigma} = W_1 + W_2 + W_3$$

3-phase apparent power

$$VA_{\Sigma} = \sqrt{W_{\Sigma}^2 + VAr_{\Sigma}^2}$$


3-phase power factor


$$\cos \phi_{\Sigma} = \frac{W_{\Sigma}}{VA_{\Sigma}}$$


Neutral current


$$An = \overline{A}_{L1} + \overline{A}_{L2} + \overline{A}_{L3}$$


Wiring diagrams















NOTE: the current inputs can be connected to the lines ONLY by means of current transformers. The direct connection is not allowed.

ATTENTION: Only one ammeter input can be connected to earth, as shown in the electrical diagrams.



Front Panel Description



1. Key-padTo program the configuration parameters and the display of the variables.



Key to enter programming and confirm selections;





Keys to:

- programme values;
- select functions;
- display measuring pages.

2. Display

LED-type with alphanumeric indications to:

- display configuration parameters;
- display all the measured variables.

Dimensions and Panel Cut-out

