


Auxiliary Contact Units

- 2 and 4 pole
- Side or front mountable
- Common use for Metasol contactors from CC9 to CC150



Selection

Туре	Апполиона	Pole	Comp	osition	Control owen moment	Mount	Wajaht
туре	Appearance	Pole	NO	NC	Contact arrangement	Mount	Weight
GUA1	A S al	2	1	1	13(43) 21(31) 1N01NC — — — — — — — — — — — — — — — — — — —	Side	53g
GUA2	00	2	2 1 -	- 1 2	53 63 51 63 51 61	Front	28g
GUA4	0000	4	4 3 2 1	- 1 2 3 4	53 630 730 83 53 610 730 83 53 610 710 83 54 64 74 84 54 62 74 84 54 62 72 84 4NO 3NO1NC 2NO2NC 51 630 710 81 51 61 710 81 52 64 72 82 52 62 72 82 1NO3NC 4NC	Front	50g

Maximum Combination of Contact Units

For contactors with AC coils	For contactors with DC coils
GUA4(on front)+GUA1 ×4EA (2EA on both sides)	GUA4(on front)+GUA1 ×2EA (1EA on both sides)
GUA2 (on front)+ GUA1 ×4EA (2EA on both sides)	GUA2(on front)+GUA1 ×2EA (1EA on both sides)




Auxiliary contact units


Rating

	Туре		GUA1	GUA2, 4	AUX100-11
Rated operat	ion voltage (Ue)		600V	600V	600V
Rated insulation voltage (Ui)			600V	600V	600V
Rated impuls	e withstand voltag	je (Uimp)	6kV	6kV	6kV
Rated freque	ncy		50/60Hz	50/60Hz	50/60Hz
Contact sens	sibility				
	Voltage		DC 17V	DC 24V	DC 24V
	Current		DC 5mA	DC 10mA	DC 10mA
Rated therma	al current (Ith, AC1	2 duty)	10A	16A	16A
Rated operat	ion current				
	AC15 duty	120V	6A	6A	6A
	(A600)	240V	3A	ЗА	3A
		380V	1.9A	1.9A	1.9A
		480V	1.5A	1,5A	1.5A
		500V	1.4A	1.4A	1.4A
		600V	1.2A	1.2A	1.2A
	DC13 duty	125V	1.1A	1.1A	1.1A
	(P600)	250V	0.55A	0.55A	0.55A
		400V	0.31A	0.31A	0.31A
		500V	0.27A	0.27A	0.27A
		600V	0.2A	0.2A	0.2A
Electrical lifet	time (mil. operatio	ns)			
	AC15 duty	220V	0.5	0.5	0.5
		440V	0.5	0.5	0.5
	DC13 duty	220V	0.5	0.5	0.5
		440V	0.5	0.5	0.5
Maximum operating cycles per hour			1800	1800	1800
Conductor size	e (Solid, stranded)	AWG	18~10	18~10	18~10
(the max_num	ber of conducts: 2)	mm ²	1~2.5	1~2.5	1~2.5

Installation



To install side mounting unit remove the indicated part in the circle in the fig. first. And then fit each part as shown. To separate push forward and pull.



To install front mounting unit fit it on the upper part of the front of the contactor and push it down. To separate pull the lever of the unit and push the unit upward.







Terminal Cover Units for Contactors

Applying contactors	Туре	Remarks
MC-185a, 225a	AP220	
(225AF)	AF 220	
MC-265a, 330a, 400a	AP400	2 pcs included
(400AF)	AP 400	z pes metuded
MC-500a, 630a, 800a	AP800	
(800AF)	AF 800	


Insulation Barrier Units




Applying contactors	Туре	Remarks
MC-185a, 225a (225AF)	A1 400	
MC-265a, 330a, 400a (400AF)	Al-400	4 pcs required per contactor
MC-500a, 630a, 800a (800AF)	AI-800	



Interlock unit





Interlocks

Component parts for assembling by customer

Interlock Unit, GUR02

GUR02 is a mechanical interlock unit and provides 2NC contacts for use in electrical interlocking


Wire Kit, UW

UW is used for making reversing circuit between two contactors.

Contactor	Wire kit		Interlock unit	
Contactor	Туре	Weight	Туре	Weight
CC9 ~ CC22	GUW22	0.04kg		
CC32 ~ CC40	GUW32	0.05kg	GUR02	0.06kg
CC50 ~ CC65	GUW63	0.12kg		
CC75 ~ CC100	GUW95	0.33kg		

Rating of the Contacts in the Interlocks

Rated operation voltage		600V
Rated insulation voltage		600V
Rated frequency		50/60Hz
Rated thermal current		10A
Rated operation current		
AC15 duty	120V	6A
(A600)	240V	3A
	380V	1.9A
	480V	1.5A
	500V	1.4A
	600V	1.2A
DC13 duty	125V	0.55A
(Q300)	250V	0.27A



Typical circuit diagram for reversing contactor






Interlock Unit, AR-180 and AR-800

AR-180 and AR-800 are mechanical interlock units in which electrical contacts for use in electrical interlocking are not included. Please use the auxiliary contacts on the sides of the contactors for that purpose.




AR-600



Contactor	Interlock unit			
Contactor	Туре	Weight		
CC180				
CC225				
CC265	AR-400	0.09kg		
CC330				
CC400				
CC500				
CC630	AR-800	15.2kg		
CC800				

Installation of Interlock and Wire Kits



Install the interlock unit on the side of a contactor first. Fit each part as indicated in the fig. And then install the other contactor on the other side of the interlock unit as shown.

After installing interlock unit wiring kit can be assembled.

Wiring kit contains two molded wires - one for line side and the other for load side.



Surge Unit

It absorbs the surge arisen out of the coil of the contactor. It can be installed simply to the contactor.

- Rated operation voltage (Ue): AC 24 ~ 440V


DC 24 ~ 125V

- Rated insulation voltage (Ui): 1000V


- Rated impulse withstand voltage (Uimp): 8kV

- Degree of protection: IP20






US-1~6




US-11~14



US-22

Surg	e unit	Potod voltago		Inter	рес.	Wainbt	
Туре	Composition	Hated	Rated voltage		R	С	Weight
GUS1	Varistor+RC		24~48V	120V	100 Ω	0.1 μF	
GUS2	Varistor+RC	AC	100~125V	270V	100 Ω	0.1 μF	
GUS3	Varistor+RC		200~240V	470V	100 Ω	0.1 μF	
GUS4	Varistor+RC		24~48V	120V	100 Ω	0.47 μF	
GUS5	Varistor+RC	DC	100~125V	270V	100 Ω	0.47μF	
GUS6	Varistor+RC		200~220V	470V	100 Ω	0.47 μF	29g
GUS11	Varistor		24~48V	120V	-	-	
GUS12	Varistor	AC/DC	100~125V	270V	-	-	
GUS13	Varistor	common	200~240V	470V	-	-	
GUS14	Varistor		380~440V	1000V	-	-	
GUS22	RC	AC	100~125V	-	56 Ω	1 μF	

Installation



Connect the lead wires to the coil terminals of the contactor first.

And then insert the body into the space of the contactor as shown above.



Capacitor Unit

Capacitor unit is connected to the terminals of the contactor to reduce the high inrush current.




		Maxim	Rated current		
Туре	Contactor	220 ~	400 ~	500 ~	(A)
		240V	440V	550V	(A)
	CC9	5	9.7	14	14
	CC12	6.7	12.5	18	18
AC9	CC18	8.5	16.7	24	24
	CC22	10	18	26	26
	CC32	15	25	36	36
	CC40	20	33.3	48	48
	CC50	20	40	58	58
AC50	CC65	25	45.7	66	66
	CC75	29.7	54	78	78
	CC85	35	60	92	92
	CC100	37	62	94	94

Note) - When the switch is closed condenser must be discharged before recharged. (Maximum residual voltage at terminals \leq 50V) prevent 30 ort current, gG type fuse must be 1.5~2 times than rated current .

Features of Capacitor Unit (Pre-loading Resistor)

- Damping resister that can limit the inrush current upto $60 \times In$ is connected to the mechanism that closed earlier than the main contact of the contactor
- No heat loss by the serial resistor
- Eliminate the switching surge
- Improving the performance of the capacitor system

Operation Sequence



Note) Closing sequence: Fig.1 => Fig.2 => Fig.3 Opening sequence: Fig.3 => Fig.1




Replacement Coil Part Numbers

Refer to contactor data sheets for full coil specifications

Contactors (3-pole only):	Coil Part Number	Nominal Coil Voltage	Coil Part Number	Nominal Coil Voltag			
CC9, CC12, CC18, CC22		no replacement coils offered					
	GCA32A24VAC50/60HZ	24 VAC 50/60Hz	GCA32A230VAC50/60HZ	230 VAC 50/60Hz			
	GCA32A48VAC60HZ	48 VAC 60Hz	GCA32A240VAC50/60HZ	240 VAC 50/60Hz			
CC32SA	GCA32A110VAC50/60HZ	110 VAC 50/60Hz	GCA32A277VAC60HZ	277 VAC 60Hz			
CC40SA	GCA32A120VAC50/60HZ	120 VAC 50/60Hz	GCA32A440VAC60HZ	440 VAC 60Hz			
	GCA32A208VAC60HZ	208VAC 60Hz	GCA32A480VAC60HZ	480 VAC 60Hz			
	GCA32A220VAC50/60HZ	220 VAC 50/60Hz	GCA32A600VAC60HZ	600 VAC 60Hz			
CC32SD	GCA32A12VDC	12 VDC	GCA32A48VDC	48VDC			
CC40SD	GCA32A24VDC	24VDC	GCA32A110VDC	110VDC			
	GCA63A24VAC50/60HZ	24 VAC 50/60Hz	GCA63A230VAC50/60HZ	230 VAC 50/60Hz			
	GCA63A48VAC60HZ	48 VAC 60Hz	GCA63A240VAC50/60HZ	240 VAC 50/60Hz			
CC50LA, CC50SA	GCA63A110VAC50/60HZ	110 VAC 50/60Hz	GCA63A277VAC60HZ	277 VAC 60Hz			
CC65LA, CC65SA	GCA63A120VAC50/60HZ	120 VAC 50/60Hz	GCA63A440VAC60HZ	440 VAC 60Hz			
	GCA63A208VAC60HZ	208VAC 60Hz	GCA63A480VAC60HZ	480 VAC 60Hz			
	GCA63A220VAC50/60HZ	220 VAC 50/60Hz	GCA63A600VAC60HZ	600 VAC 60Hz			
CC50LD, CC50SD	GCA63A12VDC	12 VDC	GCA63A48VDC	48VDC			
CC65LD, CC65SD	GCA63A24VDC	24VDC	GCA63A110VDC	110VDC			
	GCA95A24VAC50/60HZ	24 VAC 50/60Hz	GCA95A230VAC50/60HZ	230 VAC 50/60Hz			
	GCA95A48VAC60HZ	48 VAC 60Hz	GCA95A240VAC50/60HZ	240 VAC 50/60Hz			
CC75LA, CC75SA	GCA95A110VAC50/60HZ	110 VAC 50/60Hz	GCA95A277VAC60HZ	277 VAC 60Hz			
CC85LA, CC85SA	GCA95A120VAC50/60HZ	120 VAC 50/60Hz	GCA95A440VAC60HZ	440 VAC 60Hz			
CC100LA, CC100SA	GCA95A208VAC60HZ	208VAC 60Hz	GCA95A480VAC60HZ	480 VAC 60Hz			
	GCA95A220VAC50/60HZ	220 VAC 50/60Hz	GCA95A600VAC60HZ	600 VAC 60Hz			
CC75LA, CC75SA	GCA95A12VDC	12 VDC	GCA95A48VDC	48 VDC			
CC85LA, CC85SA	GCA95A24VDC	24 VDC	GCA95A110VDC	110 VDC			
CC100LA, CC100SA	GCA95A24VDC	24 VDC	GCA95ATIOVDC	110 VDC			
CC130LA, CC130SA	GCA150A24VAC50/60HZ	24 VAC 50/60Hz	GCA150A220VAC50/60HZ	220 VAC 50/60Hz			
CC150LA, CC150SA	GCA150A48VAC50/60HZ	48 VAC 50/60Hz	GCA150A500VAC50/60HZ	500 VAC 50/60Hz			
CC130LD, CC130SD	GCA150A24VDC	24 VDC	GCA150A110VDC	110 VDC			
CC150LD, CC150SD	GCA150A48VDC	48 VDC	GCAISUAIIUVDC	110 APC			
CC185	GCA225A24VACDC	24 VAC and VDC	GCA225A500VAC50/60HZ	500 VAC 50/60Hz			
CC225	GCA225A100/200VACDC	100/200 VAC and VDC	GCAZZSASUUVACSU/60HZ	300 VAC 30/60HZ			
CC265	GCA400A100/200VACDC	100/200 VAC and VDC					
CC330	•		GCA400A500VAC50/60HZ	500 VAC 50/60Hz			
CC400	GCA400A400VAC50/60HZ	400 VAC 50/60Hz					
CC500	CCAROOA100VACDC	100 VAC and VDC					
CC630	GCA800A100VACDC		GCA800A500VAC50/60HZ	500 VAC 50/60Hz			
CC800	GCA800A200VACDC	200 VAC and VDC					



Replacement Process





Safety Cover (Option)

To prevent arc from coming out from the contactor

To protect from unintended manual operation

To prevent dust from entering into the inside of the contactor



Туре	Contactor
GAP9	CC9~150
GAP185	CC185~800

